Firmware update procedure

HA1600A

The latest firmware updates and Instruction Manuals can be found at www.aimtti.com/support

To update the firmware:

- Switch on the HA1600A and select “Setup” and then “Update Software USB”.
- The HA1600A should display “Ready for data from PC”.
- Run the “HA1600_Updater_2” application.
- Click on the drop-down box (to the left of “REFRESH”) to select the COM port the HA1600A is using.
- Click “CONNECT” – You should see “Connected” displayed.
- In the “FILE” section browse for the firmware file which is included as part of this download.
- Click “SEND FILE”
- The HA1600A should indicate data being received.
- Once the update has completed, press “Restart” on the HA1600A

CAUTION



Do not remove power to the instrument during the update.