

Installation Notes

Double click on the "waveman_install.exe" program and follow the instructions on screen.

Release Notes:

Version 4.0

1. Added support for TG5011 and TG2511 generators.
2. Added ability to upload and download waveforms from supported instruments via a LAN interface.
3. When Waveform Manager launches it detects all available COM ports in the system and makes them available as options in the Upload and Download setup configuration.
4. Added a CSV file open option.
5. The default installation location of the Waveform Manager program and waveform files has been changed.

The Waveform Manager program now installs by default in "C:\Program Files\Waveman" although this may be changed during installation.

By default, Waveform Manager now stores waveforms and project files in the "Waveman" folder within the users' Documents and Settings folder.

Users of versions prior to v4.0 with existing waveforms and projects can reopen these with the **File | Open** or **File | Open_Project** menu items and navigate to the existing folder which by default was "C:\Waveman".

Version 4.01

1. Added parameterised Cardiac waveform
2. Expression library list now shown correctly first time library is viewed

Version 4.02

1. Corrected downloading of waveforms to memory stick for TG2511 and TG5011.

Version 4.03

1. Corrected a problem with upload source and download destination being incorrectly selected.

Version 4.04

1. Added support for TG2511A, TG5011A, TG2512A and TG5012A instruments